

1. Gire los dos botones de control de temperatura en OFF. Permita que se enfríe por completo de pollos de engorde. Broiler Desconecte la energía eléctrica.
2. Retire la rejilla de la parrilla. Utilice un cepillo de acero con rascador para eliminar las partículas de alimentos y residuos de las superficies de la parrilla. Lavar, enjuagar y desinfectar en la mano pileta de lavado plato. Deje que se seque al aire.
3. Aplique una ligera capa de aceite de cocina para rallar. Levante el montaje del elemento. Desmontar y limpiar la bandeja de goteo en el lavavajillas o tres fregaderos compartimiento.
5. Rocíe la superficie con una solución desengrasante y dejar solidificar para arrojarse suelos carbonizados. Limpie con un paño.
6. Remueva las partículas de alimentos persistentes con un estropajo de nylon.
7. Use un cepillo de fibra de cerdas suaves para eliminar las partículas de comida restantes de los elementos.
8. Limpie las varillas de los elementos con un paño suave y húmedo y un trabajo liviano, de uso múltiple o limpiador multiusos.
9. Vuelva a instalar la bandeja de goteo. Conjunto de elementos con cuidado bajo. Vuelva a colocar la rejilla.

Productos de Auto-Chlor Desengrasante Limpiador de uso múltiple

Auto-Chlor
SYSTEM




La frecuencia de limpieza: Diario

16 ASAR A LA PARRILLA ELECTRICA

16

ELECTRIC CHARBROILER

Cleaning Frequency: Daily



Auto-Chlor
SYSTEM

Auto-Chlor Products Degreaser All Purpose Cleaner

1. Turn both temperature control knobs OFF. Allow broiler to cool completely. Disconnect broiler from electric power.
2. Remove the grate from the broiler. Use steel brush with scraper to remove food particles and residue from grate surfaces. Wash, rinse and sanitize in hand dish wash sink. Allow to air dry.
3. Apply a light coating of cooking oil to grate.
4. Raise element assembly. Remove and clean the drip pan in dishwasher or three compartment sink.
5. Spray surface with a degreaser solution and allow to set to loosen carbonized soils. Wipe with a cloth.
6. Remove stubborn food particles with a nylon scrub pad.
7. Use a soft-bristled fiber brush to remove any remaining food particles from the elements.
8. Clean the element rods with a soft damp cloth and a light duty, all purpose or multipurpose cleaner.
9. Reinstall drip pan. Carefully lower element assembly. Reinstall the grate.

REQUIRED CLEANING TOOLS SHOWN AT LEFT