




1. Rocíe desengrasante, de uso múltiple o limpiador multiusos sobre el exterior de la máquina. Limpie la superficie con estropajo de nylon y paño húmedo.
2. Para los depósitos minerales o escala, aplicar removedor de cal al depósito mineral. Estregar con estropajo de nylon.
3. Enjuague y seque.
4. Aplique una capa fina de Auto-Chlor acero inoxidable polaco.

Productos de Auto-Chlor Limpiador de uso Múltiple Desinfectante

MÁQUINA DE LAVA PLATOS La frecuencia de limpieza: Después cada servicio de comidas




1

DISHMACHINE

EXTERIOR

Cleaning Frequency: Following Each Meal Service



Auto-Chlor[®]
SYSTEM

Auto-Chlor Products All Purpose Cleaner Sanitizing Solution

1. Spray degreaser, all purpose or multipurpose cleaner over exterior of machine. Wipe surface with nylon scrub pad and damp cloth.
2. For mineral or scale deposits, apply lime scale remover to mineral deposit. Scour with nylon scouring pad.
3. Rinse and wipe dry.
4. Apply a thin coat of Auto-Chlor Stainless Steel Polish.

REQUIRED CLEANING TOOLS SHOWN AT LEFT