




SANITIZER BUCKET & SINK

Cleaning Frequency: Daily



Auto-Chlor
SYSTEM

Auto-Chlor Products Sanitizing Solution

1. Ensure Sanitizer Bucket and third compartment sink are clean.
2. Using the Auto-Chlor dispensing system, partially fill sanitizer bucket and third sanitizer sink with sanitizer solution and water.
3. Use dry fingers to remove test strip from vial. Remove one strip and dip for one second into sink and bucket solution. Allow 5 – 10 seconds to develop, compare to color on chart in vial.
4. CHANGE WATER IN SINK AND BUCKETS ROUTINELY.
5. Maintain minimum 75°F sanitizer solution temperature.
6. Use clean cloths submerged in sanitizer bucket solution to wipe down and sanitize previously cleaned surfaces.

DISPENSE SANITIZER SOLUTION IN SPRAY BOTTLES FOR SPRAY AND WIPE SANITIZATION. APPLY SOLUTION TO SURFACE FOR 30 SECONDS BEFORE REMOVING.

REQUIRED CLEANING TOOLS SHOWN AT LEFT


Productos de Auto-Chlor Desinfectante

1. Asegúrese que el cubo de desinfectante y el fregadero de desinfectante están limpios.
2. Usando el sistema de dispensación de Auto-Chlor, llenar parcialmente el cubo de desinfectante y el tercer desinfectante fregadero con solución desinfectante y agua.
3. Utilice los dedos secos para eliminar la vial de prueba de la redoma. Retire una tira y la inmersión durante un segundo en la solución del fregadero y del cubo. Permitir 5-10 segundos para desarrollar, en comparación con el color en la carta en viales.
4. CAMBIO DE AGUA EN FREGADERO Y CUBOS RUTINARIAMENTE.
5. Mantener mínima 75 ° F la temperatura de la solución desinfectante.
6. Utilice paños limpios sumergidas en una solución desinfectante de balde para limpiar y desinfectar superficies previamente limpiadas.

DISPENSE DESINFECTANTE SOLUCIÓN EN BOTELLAS DE AEROSOL PARA LIMPIAR Y LIMPIE LA DESINFECCIÓN. APLIQUE LA SOLUCIÓN A LA SUPERFICIE PARA 30 SEGUNDOS ANTES DE RETIRAR.

PRODUCTOS DE LIMPIEZA REQUERIDOS MUESTRA A LA IZQUIERDA

Auto-Chlor
SYSTEM



EL CUBO DE
DESINFECTANTE,
EL FREGADERO DE
DESINFECTANTE
LA FRECUENCIA DE LA LIMPIEZA: DIARIO

